

1 Safety Instructions

1.1 General

- Read the user manual completely and carefully before use.
- It is part of the product and contains important information for correct use.*
- Keep this user manual.
- It must be available for uncertainties and passing the product.*
- Do not open the housing.
- Voltage-free only with pulled plug.
- Installation, assembly, maintenance and repair work must be carried out only by trained electrical specialists.
- Compare the specifications of product, power supply and peripherals. These must be identical.
- Do not repair defective products by yourself, but contact the dealer or producer.
- Do not modify or alter product nor accessories.
- Avoid stresses such as heat and cold, moisture and direct sunlight, vibration and mechanical pressure.
- Only use in dry ambience.
- Do not plug in a row.
- Do not cover the product.
- Keep vents free.
- Keep enough space around product, to ensure proper ventilation.
- Do not operate in an explosive environment.
- Secure packaging, small parts and insulation against accidental use.
- Risk of injury by stumbling and falling

1.2 Warning levels



Warnings against hazards that may result in **injuries** in case of non-observance.



Warnings against hazards that may result in **material damage** in case of non-observance.

2 Description and Function

2.1 Description

Your product is a 4-way socket cube with 2 additional USB ports for charging and operating small mobile devices with USB connection and extension cable for home use.

- With childproof
- with illuminated ON/OFF button
- with mounting lugs for wall mounting

2.2 Scope of delivery

4-way socket cube with switch and 2 USB ports, user manual

2.3 Operating elements and parts



Fig.3: Operating elements and parts

- | | |
|--|---------------------|
| 1 USB 2.0 charging ports | 2 Safety power plug |
| 3 Safety power sockets with child protection | 4 Ventilation holes |
| 5 ON / OFF switch | 6 Mounting lugs |

2.4 Specifications

Article number	41268
Connections	
Connection type 1	4X safety power socket (type F, CEE 7/4)
Connection type 2	2x USB 2.0 charging port (type A)
Connection type 3	1x safety power plug (type F, CEE 7/7)
Rated voltage / current	250 V~ 50 Hz, 16 A max.
Max. permissible load capacity	3680 W
Output voltage USB 2.0	5.0 V= , @ 2.1 A max. total
Power cord type	H05VV-F 3G 1.5 mm²
Power cord length	1.5 m
Protection class	I
Protection level	IP20
Colour	white
Dimensions (L x B x H)	9.0 x 9.0 x 8.9 cm
Weight	471 g

Tab.1: Specifications

3 Intended Use

We do not permit using the device in other ways like described in chapter Description and Function. Use the product only in dry interior rooms. Not attending to these regulations and safety instructions might cause fatal accidents, injuries, and damages to persons and property.

4 Preparing

- Compare the specifications of product, power supply and peripherals. These must be identical.
- Check the scope of delivery for completeness and integrity.

5 Installing / Mounting

5.1 Instaling

- Place the socket cube on an easily accessible, stable and horizontal surface.

5.2 Wall mounting

If required, the socket cube can also be mounted horizontally on the wall.

- Choose mounting hardware according to the substrate conditions and the product weight.

Mounting material is not included.

- Mark the drill hole distance (see fig. 1) using a suitable pencil.
- Drill the mounting holes with a suitable tool.
- Attach the socket cube.

6 Connecting




Fig.4: Connecting

- Connect your household appliances to the 4-way socket cube.
- Connect up to 2 small mobile devices with USB connection to the USB charging ports of the 4-way socket cube.
- Connect the 4-way socket cube to an easily accessible socket outlet with earthing contact.
- Switch on the 4-way socket cube by pressing the ON/OFF switch.
- An audible „click“ sound is heard and the ON/OFF switch lights red.*
- Disconnect all cable connections after use or turn the ON/OFF switch off by pressing it.
- The ON/OFF switch is no longer lit.*

7 Operating

There are no operating elements to operate during use.

8 Maintenance and Cleaning

The products are maintenance-free.



Material damage

- Clean only with a dry, soft cloth.
- Do not use cleaning agents and chemicals.
- Store cool and dry.
- Keep and use the original packaging for transport.

9 Liability notice

We reserve the right to printing errors and changes to product, packaging or product documentation.

- See our terms of warranty. These are available in their current form under the given contact details.

10 Disposal Notes



According to the European WEEE directive, electrical and electronic equipment must not be disposed with consumers waste. Its components must be recycled or disposed apart from each other. Otherwise contaminative and hazardous substances can pollute our environment.

As a consumer, you are committed by law to dispose electrical and electronic devices to the producer, the dealer, or public collecting points at the end of the devices lifetime for free. Particulars are regulated in national right. The symbol on the product, in the user's manual, or at the packaging alludes to these terms. With this kind of waste separation, application, and waste disposal of used devices you achieve an important share to environmental protection.

WEEE No: 82898622